



Note: Contact P/N is for basic contact,  
 please add suffix for plating code and,  
 for socket contacts, assembly code.

Contact P/N **90022**

**preci-dip**